



J-1480-4X PARTS LIST

PICTURE NO	ITEM NO	ITEM DESCRIPTION
1	JL100	Launching hook
2	JL103LBX	Handle for J-1480-4X
3	JL103B	Main rail frame (include 3-A ~ E)
3-A	JL210BS	Rauncher rail for J-1480-4X
3-B	Z6038	Cap 50x70
3-C	JL106	Support bar
3-E	JL108S	Connection bracket 20mm
3-F	Z6037	Plastic Base
4	JL112S	Connection pipe for J-1480-4X
5	JL118	Center frame
5-A	JL108S	Connection bracket 20mm
6	JL122	Axle frame for J-1480-4X
7	Z507	Axle shaft collar for J-1480-4X
8	JL123	Axle shaft for J-1480-4X
9	JL121	Axle bracket
10	TA30F	Spare tire type F
11	Z521	D ring
	P04-6-70	Bolt M6-70mm
	P04-6-65	Bolt M6-65mm
	P04-6-55	Bolt M6-55mm
		Nut&Spring washer M6
16	JL405	Rope 8 x1.2M

JET LAUNCHER J-1480-4X



FACTORY ZERO